

JEFTRCH22B User Manual













FEATURES

- Innovative three-in-one interchangeable lamp and torch kit with a screw thread base for solid connection allows for changing between the flexible CREE LED extension torch, slimline COB LED inspection lamp (with 360° tilt function) and CREE LED directional torch.
- Magnetic base for hands free operation
- Illuminated power indicator on the switch
- Supplied in a presentation box with a high quality USB cable and AC mains charger.

1. SAFETY

WARNING! Use only the supplied mains charger. Failure to comply with this instruction could cause injury or cause a fire, and will invalidate the warranty.

WARNING! It is the user's responsibility to read, understand and comply with the following electrical instructions:

- · Inspect the charger plug, cable and connector for damage before connecting to the mains power supply to ensure it is safe to use.
- Ensure the torch is fully charged before initial use.
- Do not expose the light to damp or wet conditions whilst charging.
- Do not handle, move or turn the torch on during the charging period.
- · Avoid shining the light in the direction of another person's or an animal's eyes.
- · Keep away from children.
- If the battery or the torch casing is damaged, do not use.
- Charge before use and recharge the battery pack every 3 months if it is not being used for a long time. Always recharge the battery after used.
- Do not open, disassemble, modify or service the battery.
- Replace only with the correct battery for this product.
- Recycle or dispose of used battery as stipulated by local regulation.
- If the electrolyte in the cells gets on your skin, thoroughly wash with soap and water.
- · If it gets in your eyes, rinse thoroughly with cool water and seek immediate medical attention.

2. OPERATION

CHARGING

- Insert USB cable into mains plug and plug into mains supply.
- · Remove USB socket cover on side of main body of torch.
- Connect the USB lead to the port on the side of the main body and a USB power socket (see fig 1).
 - Turn on the power supply.
- The power light will illumintate in red whilst charging, this will change to green to indicate that the battery has fully charged. Turn off the power supply and remove charging lead and replace socket cover.











OPERATION

Flash light torch

- · Attach torch head by screwing clockwise into main body.
- To turn on press the on/off button, once for high light brightness, again for low light brightness and once more to activate the flashing light function.
- To remove the torch head, screw the torch head anti-clockwise, this will release the torch head from the body.

Inspection lamp

- Attach inspection lamp head screwing clockwise into main body.
- The inspection lamp can be tilted through 360°.
- To turn on press the on/off button once for main light, twice to activate the directional lamp (at the end of the inspection lamp).

Flexible extension torch

- Attach flexible extension torch head by screwing clockwise into main body.
- Battery Installation/Removal
- To turn on press the on/off button, once for high light brightness, again for low light brightness and once more to activate the flashing light function.









JEFTRCH22B User Manual

LIMITED WARRANTY STATEMENT

Jefferson Professional Tools & Equipment, or hereafter "Jefferson" warrants its customers that its products will be free of defects in workmanship or material. Jefferson shall, upon suitable notification, correct any defects, by repair or replacement, of any parts or components of this product that are determined by Jefferson to be faulty or defective.

This warranty is void if the equipment has been subjected to improper installation, storage, alteration, abnormal operations, improper care, service or repair.

Jefferson will assume both the parts and labour expense of correcting defects during the stated warranty periods below.

All warranty periods start from the date of purchase from an authorised Jefferson dealer. If proof of purchase is unavailable from the end user, then the date of purchase will be deemed to be 3 months after the initial sale to the distributor.

• Jefferson Three-In-One Interchangeable LED Lamp & Torch Kit (JEFTRCH22B).

90 Days

All replacement parts purchased outside of the warranty period

Important: All parts used in the repair or replacement of warranty covered equipment will be subject to a minimum of 90 days cover or the remaining duration of the warranty period from the original date of purchase.

Warranty Registration / Activation

You can register and activate your warranty by visiting the Jefferson Tools website using the

www.jeffersontools.com/warranty and completing the online form.

Online warranty registration is recommended as it eliminates the need to provide proof of purchase should a warranty claim be necessary.

Warranty Renair

Should Jefferson confirm the existence of any defect covered by this warranty the defect will be corrected by repair or replacement at an authorized Jefferson dealer or repair centre.

Packaging & Freight Costs

The customer is responsible for the packaging of the equipment and making it ready for collection. Jefferson will arrange collection and transportation of any equipment returned under warranty. Upon inspection of the equipment, if no defect can be found or the equipment is not covered under the terms of the Jefferson warranty, the customer will be liable for any labour and return transportation costs incurred. These costs will be agreed with the customer before the machine is returned.

NOTE: * Jefferson reserve the right to void any warranty for damages identified as being caused through misuse

Jefferson will not accept responsibility or liability for repairs made by unauthorised technicians or engineers. Jefferson's liability under this warranty will not exceed the cost of correcting the defect of the Jefferson products.

Jefferson will not be liable for incidental or consequential damages (such as loss of business or hire of substitute equipment etc.) caused by the defect or the time involved to correct the defect. This written warranty is the only express warranty provided by Jefferson with respect to its products.

Any warranties of merchantability are limited to the duration of this limited warranty for the

Claiming Warranty Coverage

The end user must contact Jefferson Professional Tools & Equipment: (Tel: +44 (0) 1244 646 048) or their nearest authorised Jefferson dealer where final determination of the warranty coverage can be ascertained.

Step 1 - Reporting the Defect

Online Method:

Visit our website www.jeffersontools.com/warranty and complete the Warranty Returns form. You can complete the form online and submit it to us directly or download the form to print out and return by post.

Telephone Method:

Contact your Jefferson dealer or sales representative with the following information:

- Model number
- Serial number (usually located on the specification plate)
- Date of purchase

A Warranty Returns form will be sent to you for completion and return by post or fax, together with details of your nearest authorised Jefferson repair centre. On receipt of this form Jefferson will arrange to collect the equipment from you at the earliest convenience.

Step 2 - Returning the Equipment

It is the customer's responsibility to ensure that the equipment is appropriately and securely packaged for collection, together with a copy of the original proof of purchase. Please note that Jefferson cannot assume any responsibility for any damage incurred to equipment during transit. Any claims against a third party courier will be dealt with under the terms & conditions of their road haulage association directives.

NOTE: Jefferson will be unable to collect or process any warranty requests without a copy of the original proof of purchase.

Step 3 - Assessment and Repair

On receipt, the equipment will be assessed by an authorised Jefferson engineer and it will be determined if the equipment is defective and in need of repair and any repairs needed are covered by the warranty policy. In order to qualify for warranty cover all equipment presented must have been used, serviced and maintained as instructed in the user manual.

Where repair is not covered by the warranty a quotation for repair, labour costs and return delivery will be sent to the customer (normally within 7 working days). Note: If the repair quotation is not accepted Jefferson Professional Tools & Equipment will invoice 1 hour labour time at £30 per hour plus return carriage costs (plus VAT).

In cases where no fault can be found with the equipment, or, if incorrect operation of the equipment is identified as the cause of the problem, a minimum of 1 hour labour at £30 per hour plus carriage costs will be required before the equipment will be despatched back to the

Any equipment repaired or replaced under warranty will normally be ready for shipment back to the customer within 7 working days upon receipt of the equipment at an authorised Jefferson Repair centre (subject to part availability). Where parts are not immediately available Jefferson will contact you with a revised date for completion of the repair

General Warranty Enquiries

For any further information relating to Jefferson warranty cover please call: +44 (0) 1244 646 048 or send your enquiry via email to warranty@jeffersontools.com

The information in this document is to the best of our knowledge true and accurate, but all recommendations or suggestions are made without guarantee. Since the conditions of use are bevond their control. Jefferson Tools® disclaim any liability for loss or damage suffered from the use of this data or suggestions. Furthermore, no liability is accepted if use of any product in accordance with this data or suggestions infringes any patent. Jefferson Tools® reserve the right to change product specifications and warranty statements without further notification. All images are for illustration purposes only.

EC DECLARATION OF CONFORMITY

We, Jefferson Professional Tools & Equipment, as the authorised European Community representative of the manufacturer, declare that this equipment conforms to the requirements of the following Directives:

2014/30/EU - Electromagnetic compatibility

Signed By: Stephen McIntyre

Ancite Date: 20th June 2018

Name and address of manufacturer or authorised representative:

Jefferson Tools, Herons Way, Chester Business Park, Chester, United Kingdom, CH4 9QR

> Telephone: +44 (0)1244 646 048 Fax: +44 (0)1244 241 191 Email: enquiries@jeffersontools.com

> > www.jeffersontools.com