

94 PC

MOBILE  
STORAGE  
BIN SYSTEM



HEAVY DUTY

147KG CAPACITY



Refer to  
instructions



#### FEATURES

- ★ 64 x Small (red) bins -  
Dims: 16.3 x 10.4 x 7.4 cm
- ★ 30 x Large (blue) bins -  
Dims: 23 x 14.8 x 12.5 cm
- ★ Two-sided design facilitates  
split work areas or dividing  
types of parts.
- ★ Mounted on four  
swivel wheels with  
two lockable wheels.

#### SPECIFICATION

<b>Model No:</b>	<b>JEFBIN94WHL</b>
Small (red) bins capacity:	1 kg (per bin)
Large (blue) bins capacity:	2 kg (per bin)
Top-tray:	8 kg
Bottom-tray:	15 kg
Overall capacity weight:	147 kg
Dimensions (W x H x D):	116 x 91 x 54cm

#### MAINTENANCE

- ★ To clean the Mobile Storage Bin System, use  
and a damp cloth.
- ★ Avoid using any harsh or abrasive chemicals  
as this can damage the finish.
- ★ Avoid placing the bins in front of or close  
to heat sources.

## 1. SAFETY

- 1.1 This unit is not a toy. Children should be supervised to ensure they do not play with the Mobile Storage Bin System. This unit contains small parts and components which pose a choking hazard to children and animals. Keep these parts away from children and pets. Check the contents of the packaging against this user guide to ensure there are no missing or defective parts. Never use defective parts. Assemble only as instructed within this user guide. Any deviation or shortcut may lead to incorrect assembly or be considered customer misuse. Improper assembly may cause damage or serious injury.
- 1.2 Do not mount the Mobile Storage Bin System to a vehicle.
- 1.3 Do not overtighten any parts during assembly as this will damage the unit.
- 1.4 **WARNING!** The Mobile Storage Bin System should only be positioned on a flat stable surface.
- 1.5 Do not overload the bins. For stability, heavier items should always be placed in the bottom bins.
- 1.6 Do not rest or support items against or on the Mobile Storage Bin System.
- 1.7 **CAUTION:** To ensure continued safety, check the unit is secure and safe to use at regular intervals (every 3 months). Take appropriate action to rectify any unstable or unsafe units.
- 1.8 If you do not understand these directions, or have any doubts regarding the safety of the assembly, please seek advice and guidance from a qualified person.
- 1.9 Appropriate safety gear must be worn and precautions taken when assembling this product.
- 1.10 We recommend that two people are present to assemble this Mobile Storage Bin System.
- 1.11 **WARNING!** Do not exceed the maximum stated load capacity recommended as this may result in damage or serious injury.

## 2. CONTENTS


1. Column (x2)
2. Hanging Bars (x14)
3. Hanging Bar Supports (x6)
4. Top Tray
5. Bottom Tray
6. Column Supports (x4)
7. Castor with Brake (x2)
8. Castor Without Brake (x2)
9. Handle
10. Handle Bracket (x2)

**Plus:**

- Small Bin (not shown) (x64)
- Large Bin (not shown) (x30)


**Also contains:**

- M4x9 Screw (x42)
- M6x10 Screw (x26)
- M6x35 Screw (x4)
- M6 Nut (x28)
- M6x15 Screw (x2)



### 3. ASSEMBLY

- 3.1 Attach both Castors with Brake (7) to the flat, bottom of the Bottom Tray (5). Attach both Castors with Brake along the same end as shown. Secure each Castor with Brake in place with four Screws (12) and Nuts (14). Repeat this step for the Castors without Brake (8).
- 3.2 Attach Hanging Bars (2) to each Column (1), secure the Hanging Bars in place by snapping into place on each side of the Hanging Bar tabs on each column.
- 3.3 Attach the Hanging Bar Supports (3) to the ten Hanging Bars. Secure in place with Screws (11).  
Note: Check that all Hanging Bar holes are aligned before attaching Hanging Bar Supports.
- 3.4 Attach both columns to Bottom Tray (5). Secure in place with Screws (13) and Nuts (14).
- 3.5 Attach the ends of two Column Supports (6) placed together to the bottom of each Column with one Screw (15) per column. Attach the other ends of the Column Supports to the Bottom Tray with screws (12) and nuts (14).
- 3.6 Secure Top Tray (4) to the Top Tray tabs at the top of both Columns with Screws (12) and Nuts (14).
- 3.7 Attach lower Handle Bracket (10) to Column. Secure with a Screw (12). Hold Handle (9) onto attached Bracket, and then attach other Handle Bracket to Column to secure Handle in place.
- 3.8 Arrange Bins as desired. Slide Bin lip over Hanging Bar, making certain Bin is securely in place.



## LIMITED WARRANTY STATEMENT

Jefferson Professional Tools & Equipment, or hereafter "Jefferson" warrants its customers that its products will be free of defects in workmanship or material. Jefferson shall, upon suitable notification, correct any defects, by repair or replacement, of any parts or components of this product that are determined by Jefferson to be faulty or defective.

This warranty is void if the equipment has been subjected to improper installation, storage, alteration, abnormal operations, improper care, service or repair.

### Warranty Period

Jefferson will assume both the parts and labour expense of correcting defects during the stated warranty periods below.

All warranty periods start from the date of purchase from an authorised Jefferson dealer. If proof of purchase is unavailable from the end user, then the date of purchase will be deemed to be 3 months after the initial sale to the distributor.

#### 1 Year

- Jefferson 94PC Mobile Storage Bin System [JEFBIN94WHL].

#### 90 Days

- All replacement parts purchased outside of the warranty period

Important: All parts used in the repair or replacement of warranty covered equipment will be subject to a minimum of 90 days cover or the remaining duration of the warranty period from the original date of purchase.

### Warranty Registration / Activation

You can register and activate your warranty by visiting the Jefferson Tools website using the following address: [www.jeffersonstools.com/warranty](http://www.jeffersonstools.com/warranty) and completing the online form.

Online warranty registration is recommended as it eliminates the need to provide proof of purchase should a warranty claim be necessary.

### Warranty Repair

Should Jefferson confirm the existence of any defect covered by this warranty the defect will be corrected by repair or replacement at an authorized Jefferson dealer or repair centre.

### Packaging & Freight Costs

The customer is responsible for the packaging of the equipment and making it ready for collection. Jefferson will arrange collection and transportation of any equipment returned under warranty. Upon inspection of the equipment, if no defect can be found or the equipment is not covered under the terms of the Jefferson warranty, the customer will be liable for any labour and return transportation costs incurred. These costs will be agreed with the customer before the machine is returned.

NOTE: \* Jefferson reserve the right to void any warranty for damages identified as being caused through misuse \*

### Warranty Limitations

Jefferson will not accept responsibility or liability for repairs made by unauthorised technicians or engineers. Jefferson's liability under this warranty will not exceed the cost of correcting the defect of the Jefferson products.

Jefferson will not be liable for incidental or consequential damages (such as loss of business or hire of substitute equipment etc.) caused by the defect or the time involved to correct the defect. This written warranty is the only express warranty provided by Jefferson with respect to its products.

Any warranties of merchantability are limited to the duration of this limited warranty for the equipment involved.

### Claiming Warranty Coverage

The end user must contact Jefferson Professional Tools & Equipment: (Tel: +44 (0) 1244 646 048) or their nearest authorised Jefferson dealer where final determination of the warranty coverage can be ascertained.  
Step 1 - Reporting the Defect

### Online Method:

Visit our website [www.jeffersonstools.com/warranty](http://www.jeffersonstools.com/warranty) and complete the Warranty Returns form. You can complete the form online and submit it to us directly or download the form to print out and return by post.

### Telephone Method:

Contact your Jefferson dealer or sales representative with the following information:

- Model number
- Serial number (usually located on the specification plate)
- Date of purchase

A Warranty Returns form will be sent to you for completion and return by post or fax, together with details of your nearest authorised Jefferson repair centre. On receipt of this form Jefferson will arrange to collect the equipment from you at the earliest convenience.

### Step 2 - Returning the Equipment

It is the customer's responsibility to ensure that the equipment is appropriately and securely packaged for collection, together with a copy of the original proof of purchase. Please note that Jefferson cannot assume any responsibility for any damage incurred to equipment during transit. Any claims against a third party courier will be dealt with under the terms & conditions of their road haulage association directives.

NOTE: Jefferson will be unable to collect or process any warranty requests without a copy of the original proof of purchase.

### Step 3 - Assessment and Repair

On receipt, the equipment will be assessed by an authorised Jefferson engineer and it will be determined if the equipment is defective and in need of repair and any repairs needed are covered by the warranty policy. In order to qualify for warranty cover all equipment presented must have been used, serviced and maintained as instructed in the user manual.

Where repair is not covered by the warranty a quotation for repair, labour costs and return delivery will be sent to the customer (normally within 7 working days). Note: If the repair quotation is not accepted Jefferson Professional Tools & Equipment will invoice 1 hour labour time at £30 per hour plus return carriage costs (plus VAT).

In cases where no fault can be found with the equipment, or, if incorrect operation of the equipment is identified as the cause of the problem, a minimum of 1 hour labour at £30 per hour plus carriage costs will be required before the equipment will be despatched back to the customer.

Any equipment repaired or replaced under warranty will normally be ready for shipment back to the customer within 7 working days upon receipt of the equipment at an authorised Jefferson Repair centre (subject to part availability). Where parts are not immediately available Jefferson will contact you with a revised date for completion of the repair.

### General Warranty Enquiries

For any further information relating to Jefferson warranty cover please call: +44 (0) 1244 646 048 or send your enquiry via email to [warranty@jeffersonstools.com](mailto:warranty@jeffersonstools.com)

### Disclaimer:

The information in this document is to the best of our knowledge true and accurate, but all recommendations or suggestions are made without guarantee. Since the conditions of use are beyond their control, Jefferson Tools® disclaim any liability for loss or damage suffered from the use of this data or suggestions. Furthermore, no liability is accepted if use of any product in accordance with this data or suggestions infringes any patent. Jefferson Tools® reserve the right to change product specifications and warranty statements without further notification. All images are for illustration purposes only.